BOMBAY OUTLET

2288189
Bentley The Butler
Parts and Hardware List

A.	Body Assembly	1 pc
B.	Base	1 pc
C.	Tray Assembly	1 pc
D.	Long Phillips Head Bolts	2 pcs
E.	Short Phillips Head Bolts	2 pcs
F.	Phillips Head Screwdriver	1 pc
G.	Large Flat Washers	2 pcs
H.	Large Lock Washers	2 pcs
I.	Small Flat Washers	2 pcs
J.	Small Lock Washers	2 pcs
K.	Wire Glasses	1 pair

∗ Please make sure that you have all the parts and hardware indicated above before you begin assembly of this item.
∗ Use the hardware illustrations to determine correct piece and size.
∗ This item should be assembled on a soft surface to prevent scratching the finish during assembly.
∗ This item may require periodic tightening.

Hardware Illustrations



D. Long Phillips Head Bolt



E. Short Phillips Head Bolt



G. Large Flat Washer



H. Large Lock Washer



I. Small Flat Washer



J. Small Lock Washer

2288189
Bentley The Butler

Attach the Base &Tray Assembly

1. **Attach Base (B)** Secure the Base (B) to the Body Assembly (A) with Short Phillips Head Bolts (E), Large Lock Washers (H) and Large Flat Washers (G).
2. Place Bentley in a standing position.
3. **Attach Tray Assembly (C)** Align the pre-drilled holes in the bottom of the Tray Assembly (C) with the pre-drilled holes in Bentley's hands. Secure the Tray Assembly (C) to the Body Assembly (A) with Long Phillips Head Bolts (E), Small Lock Washers (J) and Small Flat Washers (I).
4. Put Wire Glasses (K) on.